



= : \

of glass / dish / utensil

and hood-type dishwashers

The recommissioning should be done by an authorised HOBART service provider.

		CHECK	
1	Recommissioning without prior shutdown of the machine	Check condition of the peristaltic hoses (detergent / rinse aid) and replace if necessary	
2	Recommissioning without prior shutdown of the machine	Check dosing pumps and flow (detergent dosing nipple may be blocked)	
3	Recommissioning	Check the detergent and rinse aid hoses and replace if necessary (chemical container to the dosing device)	
4	Recommissioning	Please follow the instruction in operatinon manual as mentioned in chapter "operation"	
5	Recommissioning	The chemical suction hoses have to be inserted back into the external chemical container	
6	Recommissioning	Re-filled suction hoses with chemicals manually	
7	Softening system recommissioning	Flow the pillar	
8	Reverse osmosis recommissioning	Flow membranes	
9	Partial and full demineralization recommissioning	Flow the cartridge	
10	Recommissioning	Drain the machine and restart - 3 rinse cycles	
11	Recommissioning PROFI and PREMAX dishwasher	Hygiene programe carried out with HYGIENE-TAB	